

Programming RTC Black Remote to TV
(if you know your programming code)

Turn on the TV.

Press the “TV” button at the top of the remote.

Hold the “RCU Setup” button until the light on the TV button blinks twice.

Put your code in, then lock it in by hitting the “RCU Setup” button again.

Programming RTC Black Remote to TV
(if you don't know your programming code)

Turn on the TV.

Press the “TV” button at the top of the remote.

Hold the “RCU Setup” button until the light on the TV button blinks twice.

Press “991”

Press the “Power” button at the top of the remote.

Press the “Channel Up” button slowly until the TV turns off.

Press the “RCU Setup” button to lock in the code.